

## D2 RUST

### PRODUCT DESCRIPTION:

Specific spotting agent for rust and other oxidation stains for both dry cleaning and laundry. It can be used both in pre-spotting and post-spotting.

Improved formula for the safety of the user.

Usually stains consist of various components so often it is necessary to use different products to complete the process of elimination of the stains. If you have a doubt on the composition of the stain start with D4 – Proteiche and do not use vapour to avoid fixing the stain.

### HOW TO USE:

For identified stains see the D Line spotting table in order to follow the correct sequence of the spotting agents to avoid fixing stains.

#### Use:

1. Wet the stain with water
2. Apply some drops of pure D2, on the stain
3. Leave the product act for 15-30 seconds using a brush or a spatula if necessary
4. Heat with a steam gun if necessary
5. Rinse thoroughly with water and dry with compressed air
6. Repeat the treatment if necessary

Attention: Before use test the product on a hidden part of the garment

**Product for professional use only.**

### LOGISTIC INFORMATION:

Code	Packaging	Box	Pallet
A15-040A	500 ml	6 pcs.	-

### CLP REGULATION:

#### Contains (Reg.CE 648/2004):

> 30% phosphate

#### Ingredients:

> 35% phosphoric acid

**Danger:** Causes severe skin burns and eye damage. Do not breathe vapours. Wash hands thoroughly after handling. Wear protective gloves/protective clothing/eye protection/face protection. IF SWALLOWED: rinse mouth. Do NOT induce vomiting. IF ON SKIN (or hair): Remove/Take off immediately all contaminated clothing. Rinse skin with water/shower. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a POISON CENTER or doctor/physician. Dispose of contents/container in accordance with local and national regulations.



**STORAGE:** Keep the product in its original packaging at a temperature between 10 and 35 ° C and avoid any leakage of product. Avoid bitter cold and freezing. Do not expose to direct sunlight. It is advisable to preferably use the product within 18 months from production. For further information read the safety data sheet (SDS).

All the instructions provided are the result of studies and experiences acquired and they do not exempt the client from verifying the suitability of the products for the purposes of use. Therefore the application of the products and the results obtained must be considered independent from our responsibility.

**CONTACTS:**

Tintolav s.r.l.

Via M. D'Antona, 7, 10028 Trofarello (TO) – Italy

+39 011 6496827 r.a.

[info@hygienfresh.it](mailto:info@hygienfresh.it) / [www.hygienfresh.it](http://www.hygienfresh.it)

**STORAGE:** Keep the product in its original packaging at a temperature between 10 and 35 ° C and avoid any leakage of product. Avoid bitter cold and freezing. Do not expose to direct sunlight. It is advisable to preferably use the product within 18 months from production. For further information read the safety data sheet (SDS).

All the instructions provided are the result of studies and experiences acquired and they do not exempt the client from verifying the suitability of the products for the purposes of use. Therefore the application of the products and the results obtained must be considered independent from our responsibility.