

D4 PROTEIN

PRODUCT DESCRIPTION:

Specific spotting agent for dry cleaning and laundry for stains of blood, eggs, milk, ice-cream, to be used in pre-spotting. Enzymatic product with dissolving effect on the stain. Stains are usually composed of various elements, so it's often necessary to use different products to complete the stain elimination process. If you have a doubt about the composition of the stain, start with D4 – Proteiche and do not use steam, to avoid fixing the stain.

HOW TO USE:

For stains that have been identified, see D line spotting table in order to follow the correct sequence of spotting agents to avoid fixing stains.

Use:

1. Wet the stain with some water.
2. Apply some drops of pure D4 on the stain.
3. Let the product act for 15-30 seconds and use a brush or a scraper if necessary.
4. Rinse with plenty of water and dry with compressed air.
5. Repeat the treatment if necessary.

Attention: Before use test the product on a hidden part of the garment
Product for professional use only.

LOGISTIC INFORMATION:

Code	Packaging	Box	Pallet
A15-060A	500 ml	6 pcs.	-

CLP REGULATION:

Contains (Reg.CE 648/2004):

≥5%<15% anionic surfactants

<5% enzymes

Ingredients:

aqua, glycerin, tea-dodecylbenzenesulfonate, cocamide dea, butoxydiglycol, C13-15 pareth-7, meq-borate, diethanolamine, subtilisin, triethanolamine, α-amylase, lipase, cellulase, dimethicone, steareth-21, **[methylchloroisthiazolinone, methylisothiazolinone (3:1) = 0,0003%]**.

Danger: Causes skin irritation. Causes serious eye damage. Contains the highlighted ingredients. May produce an allergic reaction. Wear protective gloves / protective clothing / eye protection / face protection. Immediately call a POISON CENTER or doctor / physician. IF ON SKIN: Wash with plenty of water and soap. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. If skin irritation occurs: Get medical advice / attention.



STORAGE: Keep the product in its original packaging at a temperature between 10 and 35 ° C and avoid any leakage of product. Avoid bitter cold and freezing. Do not expose to direct sunlight. It is advisable to preferably use the product within 18 months from production. For further information read the safety data sheet (SDS).

All the instructions provided are the result of studies and experiences acquired and they do not exempt the client from verifying the suitability of the products for the purposes of use. Therefore the application of the products and the results obtained must be considered independent from our responsibility.

**CONTACTS:**

Tintolav s.r.l.

Via M. D'Antona, 7, 10028 Trofarello (TO) – Italy

+39 011 6496827 r.a.

info@hygienfresh.it / www.hygienfresh.it

STORAGE: Keep the product in its original packaging at a temperature between 10 and 35 ° C and avoid any leakage of product. Avoid bitter cold and freezing. Do not expose to direct sunlight. It is advisable to preferably use the product within 18 months from production. For further information read the safety data sheet (SDS).

All the instructions provided are the result of studies and experiences acquired and they do not exempt the client from verifying the suitability of the products for the purposes of use. Therefore the application of the products and the results obtained must be considered independent from our responsibility.